

Please read the entire instruction carefully before using FUSIFY.

1. Start the engine and warm it up to operating temperature by letting it idle for 15 minutes, or perform the application process immediately after driving a few miles.
2. Stop the engine, open the hood, locate the oil compartment cap, remove the red protective cap from the FUSIFY applicator.
3. Unscrew the oil compartment cap and squeeze FUSIFY from the applicator directly into the oil compartment.
4. If your car has an engine oil filler tube, mix the contents of the FUSIFY applicator with 1/8 quart of engine oil and pour the mixture into the oil filler tube.
5. Tighten the oil compartment (or oil filler tube) cap and close the engine hood.
6. Start the engine and let it idle for 15 minutes to allow the FUSIFY to thoroughly mix with the engine oil.
7. Do not change engine oil for the next 1,000 miles after using FUSIFY.
8. That's it, your engine is protected for the next 40,000 miles!

The optimal and recommended procedure is the application of FUSIFY immediately after a standard change of oil and oil filter in the car.

We suggest that you drive the first 150 miles after FUSIFY application not exceeding 3,000 RPM engine speed.

Date:...../...../.....

Mileage:.....

Fill fields above and keep this instruction for further reference.